



Hand controll TH14

For the lifting columns TL3 and TL 18, the desired hand control must be selected. We also recommend ordering fittings for attaching the control box (2 pcs for 4-parallel columns). For TL3, a top and bottom plate must be ordered in addition, 2 per column.

Article.no

Article.no

200087